

C.A.R. PRODUCTS®

makers of fine cleaners

630 Beaulieu Street, Holyoke, MA 01040
Phone 1-800-537-7797 Fax 1-413-536-9979

**MELT-AWAY
PART #ICS-171
TITRATION PROCEDURE
TITRATION KIT #2
01/05/06**

1. COLLECT SAMPLE FROM APPLICATION NOZZLE, USING 16 OZ. TEST KIT CONTAINER.
2. FILL PLASTIC VIAL TO 25 ML. MARK.
3. ADD 2 DROPS INDICATOR A.
4. ADD SOLUTION 2 DROPWISE, WITH CONTINUAL SWIRLING UNTIL ORIGINAL COLOR APPEARS. RECORD NUMBER OF DROPS USED.

<u>USAGE</u>	<u>DROPS</u>
½ %	8-9
¾ %	12-13
1 %	17
1 ½ %	25-26
2 %	34
2 ½ %	42-43
3 %	51
3 ½ %	59-60
4 %	68

THESE % ARE THE
RECOMMENDED
CLEANING RANGES
FROM MIN. TO MAX.

DROP AMOUNTS
MAY VARY BY ½

