

C.A.R. PRODUCTS®

makers of fine cleaners

630 Beaulieu Street, Holyoke, MA 01040
Phone 1-800-537-7797 Fax 1-413-536-9979

**NICE & WHITE
PART #ICS-303
TITRATION PROCEDURE
TITRATION KIT #3**

1. COLLECT SAMPLE FROM APPLICATION NOZZLE, USING A CLEAN DRY CONTAINER.
2. FILL PLASTIC VIAL TO 10 ML. MARK.
3. EMPTY PLASTIC VIAL WITH 10 ML. SAMPLE INTO 16 OZ. TEST KIT CONTAINER
4. ADD 300 ML. OF WATER WITH CONTINUAL SWIRLING (USE PLASTIC VIAL FOR MEASUREMENT). PUT CAP ON AND MIX THOROUGHLY.
5. RETURN 25 ML. OF DILUTED SOLUTION TO PLASTIC VIAL.
6. ADD 2 DROPS INDICATOR A.
7. ADD SOLUTION 3 DROPWISE, WITH CONTINUAL SWIRLING UNTIL ORIGINAL COLOR APPEARS. RECORD NUMBER OF DROPS USED

USAGE

4:1

6:1

8:1

DROPS

14 DROPS

10 DROPS

7 DROPS

THESE % ARE THE
RECOMMENDED
CLEANING RANGES
FROM MIN. TO MAX.

DROP AMOUNTS
MAY VARY BY ½

